



TO GET THE MOST *from* YOUR EVEREST BLOWERS

MAKE SURE proper oil levels are maintained in the gear & grease/oil in the bearing end.

CHECK OIL level and grease every 40 hours of operation. Loss of oil or grease should be replenished.

FIRST OIL change should be done within the first 100 operating hours and thereafter every 1000 hours or more often, if oil gets dirty.

CHECK BELT tension every fortnight. Too tight belts would cause premature bearing failure while too loose belts would cause overheating of belts and pulleys.

CHECK REGULARLY for any knocking or abnormal sound. High frequency sound indicates bearing trouble. Knocking sound indicates rotor timing upset. Contact “Everest” for necessary adjustments.

CLEAN AIR filter every fortnight. Choked filter would result in excessive power consumption and overheating of blower. Replace filter every three months or earlier.

CHECK and CLEAN air silencer every month.



Corporate Office

B-44, Mayapuri Industrial Area, Phase1, New Delhi 110 064, India
Tf: +91 11 4545 7777 | E: info@everestblowers.com

Group Companies

Everest Blowers - Everest Transmission - Everest Blower Systems



www.everestblowers.com